Getty













TECHNICIAN TRAINING FOR THE CONSERVATION OF MOSAICS

PART 2
THE CONSERVATION OF DETACHED MOSAICS

The conservation of mosaics kept in storage

Livia Alberti, Ermanno Carbonara, Thomas Roby



Often a large number of mosaics removed from their original site are stored in a repository. Mosaics can be stored on new supports or without any support on support structures. Sometimes mosaics are kept in storage without any type of support, simply rolled up on their facing fabric. In all cases, it is necessary to correctly preserve the mosaic sections or fragments, creating new supports for them and appropriate storage structures.



Mosaics kept in storage on new supports



Honeycomb aluminum panel



Reinforced concrete panel

Mosaics kept in storage without supports, on support planks



On metal shelves



One on top of another

Mosaics kept in storage without a new support

Examples



Mosaics put in storage on metal shelves on plywood panels





Mosaics put in storage one on top of another on particleboard panels



Mosaics put in storage one on top of another on plywood panels



Mosaics put in storage on a wooden plank panel



Mosaics put in storage without any support structure



Characteristics and functionalities of long-term storage installations for mosaics

- Rigidity and stability of materials to be used
- Dimensions appropriate for mosaic sections/fragments
- Adequate weight-bearing capacity of the structure
- Accessibility of mosaic sections/fragments
- Optimization of space to be used
- Sustainability of construction and maintenance costs of the structure

Particleboard panels

ADVANTAGES

- Inexpensive
- Readily available

- Easily deformed in the short term
- Low stability to humidity
- Low weight-bearing capacity
- Maintenance needs





Plywood panels

ADVANTAGES

- Inexpensive
- Readily available
- Good weight-bearing capacity

- Easily deformed in the medium term
- Low stability to humidity
- Maintenance needs





Wooden planks

ADVANTAGES

- Readily available
- Good weight-bearing capacity

- Expensive
- Easily deformed in the medium term
- Low stability to humidity
- Maintenance needs





Painted or galvanized iron

ADVANTAGES

- Good stability
- Not easily deformed
- Very good weight-bearing capacity
- Low maintenance needs

- Expensive
- Not readily available





Aluminum

ADVANTAGES

- Stable
- Not easily deformed
- Very good weight-bearing capacity
- No maintenance needs

- Expensive
- Not readily available





Polyethylene

ADVANTAGES

- Stable
- Not easily deformed
- Good weight-bearing capacity
- No maintenance needs

- Expensive
- Not readily available






Primary deterioration phenomena of mosaics kept in storage without a new support

- Deformation of sections
- Detachment of tesserae
- Growth of micro-organisms
- Tearing of the fabric/paper
- Disintegration of the fabric/paper

- Inappropriate support materials for sections/fragments
- Inappropriate storage structure
- High humidity



- Deformation of sections
- Detachment of tesserae
- Growth of micro-organism
- Tearing of the fabric/paper
- Disintegration of the fabric/paper

- High humidity
- Presence of light (ultraviolet)
- Variations in temperature and humidity



- Deformation of sections
- Detachment of tesserae
- Growth of micro-organisms
- Tearing of the fabric/paper
- Disintegration of the fabric/paper

- High humidity
- Presence of light (ultraviolet)



- Deformation of sections
- Detachment of tesserae
- Growth of micro-organisms
- Tearing of the fabric/paper
- Disintegration of the fabric/paper

- Inadequate removal procedure and materials
- Incorrect manipulation of sections during storage



- Deformation of sections
- Detachment of tesserae
- Growth of micro-organisms
- Tearing of the fabric/paper
- Disintegration of the fabric/paper



- High humidity
- Presence of light (ultraviolet)
- Variations in temperature and humidity
- Inadequate removal materials and procedure
- Presence of animals in the repository



Intervention phases:

- 1. Documentation and cataloging of mosaic sections/fragments
- 2. Stabilization of the tessellatum
- 3. Creation of temporary support
- 4. Placement of sections/fragments in the storage structure

1. Documentation and cataloging of mosaic sections/fragments

- Identification of sections by creating a database and a data archiving system.
- Graphic and photographic documentation of the Condition Assessment of each mosaic section.

Treatments of mosaics kept in storage without a new support

_	ID Mosaic											
	Location in the storage room											
-	Temporary numbering	S001	SOC	12	S003	S004	S005	S006	S007	S008	S009	S010
IDENTIFICATION	Previous numbering - panel			-								
₫	Previous numbering - facing	_										
Ē	Original location- site	_										
B	Original location- room/mosaic	_										
	Maximum dimensions (cm)	_										
	Surface area (m²)	_										
	Tessera dimensions											
	Tessera dimensions											
CONSTRUCTION TECHNIQUE	Material tessera color											
포	Material tessera color											
Ĭ	Material tessera color											
Ñ.	Material tessera color											
SC.	Material tessera color											
ΕŞ	Material tessera color											
8	Density of the tesserae (no. in 20x20 cm)											
	Interstices											
	Note on the construction technique											
	Type of facing used											
. ≩	Type of adhesive used											
IN TE	Type of adhesive used Other interventions											
	Resettable detached tesserae (no.)											
	Loose non-resettable tesserae (no.)											
Z	Deteriorated tesserae (no.)		_									
XIX	Presence of original bedding mortar	_	_	-								
CONDITION	Other	+	1	_			+	+				
			-									
83	Location in the new storage											
	Photographic documentation folder name											
NEW	Graphique documentation folder name											

Livia Alberti, Cristina Caldi, Thomas Roby 2018 © J. Paul Getty Tru



2. Stabilization of the tessellatum

- Collect and keep tesserae that are no longer in their original position in a small container.
- Clean the back of the tesserae with a brush and vacuum cleaner, avoiding the detachment of tesserae from the facing fabric/paper.
- Readhere the detached tesserae to the facing with an adhesive, keeping their original position and orientation.





3. Creation of a new temporary support

- Apply a layer of clay to the back of the sections/fragments and invert them (Photo 1).
- Dissolve the facing adhesive with an appropriate solvent, depending on the type of adhesive used and remove the facing fabric, verifying that the tesserae do not detach from the clay bedding layer (Photo 2, 3).
- Apply a new facing fabric layer (one or more) to the surface of the mosaic using an appropriate adhesive (Photo 4).
- Invert the mosaic sections/fragments and remove the clay layer (Photo5).
- Apply an initial layer of a weak lime-based mortar to the back of the tesserae (Photo 6).
- Apply a second layer of mortar reinforced with natural fibers (hemp, cotton, horse hair) or synthetic fibers (polyester, carbon) (Photo 7).
- Apply a layer of wide weave natural fabric (cotton gauze or fabric) or synthetic fabric (polyester) with an adhesive (acrylic or vinyl) with aggregates, if necessary (Photo 8).

















4. Placement of sections/fragments in the storage structure

- Dissolve the facing adhesive with an appropriate solvent, depending on the type of adhesive used and remove the fabric, verifying that the tesserae do not detach from the bedding layer.
- Store the sections/fragments with an identification code corresponding to the previously created catalog.







Documentation for mosaics kept in storage

MOSAIKON Technician Training for the Conservation of Mosaics – Getty Conservation Institute, 2020 © J. Paul Getty Trust, www.getty.edu

Inventory of mosaic fragments/sections in storage

LOCATION:	DATE://
-----------	---------

	ID Mosaic																			
	Location in the storage room																			
z	Temporary numbering	S001	S002	2	SC	003	SO	04	SC	005	SO	06	SC	07	SO	008	SC	09	SO	10
OE.	Previous numbering - panel																			
\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Previous numbering - facing																			
IDENTIFICATION	Original location- site																			
IDE	Original location- room/mosaic																			
	Maximum dimensions (cm)																			
	Surface area (m²)																			
	Tessera dimensions																			
	Tessera dimensions					1				1				1						
CONSTRUCTION TECHNIQUE	Material tessera color																			
H	Material tessera color																			
ΉL	Material tessera color																			
ĮOT.	Material tessera color																			
RUC	Material tessera color																			
ISNO	Material tessera color																			
S	Density of the tesserae (no. in 20x20 cm)																			
	Interstices																			
	Note on the construction technique																			
	Type of facing used																			
۲. RV.	Type of adhesive used																			
PREV. INTERV.	Other interventions																			
	Resettable detached tesserae (no.)																			
	Loose non-resettable tesserae (no.)																			
N	Deteriorated tesserae (no.)																			
DITIC	Presence of original bedding mortar																			
CONDITION	Other																			
SES	Location in the new storage																			
3ENC	Photographic documentation folder name																			
NEW REFERENCES	Graphique documentation folder name																			
ZZ																				

Glossary of inventory of mosaic fragments/sections in storage

		GLOSSARY
	ID Mosaic	to establish according to the original location of the fragment/section (site - building - room - no. of the fragment/section)
	Location in the storage room	shelf (S) and panel (P) of the storage structure; refer to a drwaing or photo of the structure where the numbering is shown (shelves from left to right, panels from below up), ex. S02-P08
z	Temporary numbering	consecutive numbers
E	Previous numbering - panel	if marked on the panel
½	Previous numbering - facing	if marked on the facing
DENTIFICATION	Original location- site	if known
≌	Original location- room/mosaic	if known
	Maximum dimensions (cm)	the largest dimensions that can be measured on two orthogonal axes.
	Surface (m²)	to be calculated
	Tessera dimensions	choose among the following categories: 0-6 mm (A), 6-10 mm (B), 10-15 mm (C) and > 15 mm (D)
H.	Tessera dimensions	"
CONSTRUCTION TECHNIQUE	Material tessera color	choose among the following materials: Stone/Marble (S/M), Ceramic (C) and Glass (G), or Not Identifiable (NI) and following colors: White (W), Beige (Be), Grey (G), Black (B), Yellow (Y), Green (G), Red (R) and Other(O)
=	Material tessera color	" "
	Material tessera color	п
30C	Material tessera color	п
ST	Material tessera color	п
9	Density of the tesserae (no. in 20x20 cm)	number of tesserae in a square of 20 x 20 cm
	Interstices	choose among the following categories: 0 mm (A), 0-1 mm (B), 1-2 mm (C) and > 2 mm (D)
	Type of facing used	choose among the following materials: Gauze (Ga), Fabric (F), Paper (P) and Other (O)
	Type of adhesive used	choose among the following materials: Vinyl adhesive (V), Acrylic adhesive (Ac), Animal glue (A), or Not Identifiable (NI)
PREV.	Type of adhesive used Other interventions	note other types of interventions
	Resettable detached tesserae (no.)	number of detached tesserae which are still in their place on the facing
NO NO	Loose non-resettable tesserae (no.)	number of detached tesserae which have lost their place on the facing
CONDITION	Deteriorated tesserae (no.)	number of fractured, disaggregated, eroded tesserae
8	Presence of original bedding mortar	yes / no
	Other	note other types of deterioration
V ERENCES	Location in the new storage	shelf (S) and panel (P) of the new storage structure; refer to the numbering present on the structure and on the drawing or photograph of the storage, ex. S1-P12
	Photographic documentation folder name	
NEW REFEI	Graphic documentation folder name	

MOSAIKON Technician Training for the Conservation of Mosaics – Getty Conservation Institute, 2020 © J. Paul Getty Trust, www.getty.edu

Legends for graphic documentation

LEGEND - CONDITION AND CURRENT INTERVENTIONS MAP 1 **BACK OF THE TESSELLATUM** Mosaic fragment/section ID: Loss of tesserae within the fragment/section Presence of original mortar preparation layers Presence of roots Deteriorated tesserae consolidated with: Detached tesserae re-adhered to the facing with: Tesserae reset on a reinforced facing (fabric, paper or gauze) with:

FRONT OF THE TESSELLATUM Mosaic fragment/section ID:
Area of loss in the old fabric/paper facing
Loose tesserae (kept in a container)
Tesserae reset on clay
Infilling of lacunae with:
Filling of interstices with:
Reference lines present on the old facing

PREPARED BY:

DATE:

PREPARED BY:

DATE:

Getty













MOSAIKON is a partnership of four institutions: the Getty Conservation Institute, the Getty Foundation, ICCROM, and ICCM. The aims of the project are to strengthen the network of professionals concerned with the conservation, restoration, maintenance, and management of mosaic heritage in the southern and eastern Mediterranean region; provide training to a variety of individuals involved in mosaics conservation and, more generally, with the management of archaeological sites and museums with mosaics; work with national and international bodies to provide a more favorable legislative, regulatory, and economic environment for the conservation of mosaics in the Mediterranean; and promote the dissemination and exchange of information.

